DetectShush.py

```
import numpy as np
2
   import cv2
3
  import os
4 from os import listdir
   from os.path import isfile, join
6
   import sys
7
8
   def detectShush(frame, location, ROI, cascade):
9
       mouths = cascade.detectMultiScale(ROI, 1.15, 3, 0, (20, 20))
10
       for (mx, my, mw, mh) in mouths:
           mx += location[0]
11
           my += location[1]
12
13
           cv2.rectangle(frame, (mx, my), (mx+mw, my+mh), (0, 0, 255), 2)
       return len(mouths) == 0
14
15
   def detect(frame, faceCascade, mouthsCascade):
16
17
       gray_frame = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
18
19
        gray_frame = cv2.equalizeHist(gray_frame)
20
        gray_frame = cv2.medianBlur(gray_frame, 5)
21
22
       faces = faceCascade.detectMultiScale(
23
                    gray_frame, 1.15, 4, 0|cv2.CASCADE_SCALE_IMAGE, (40, 40))
24
       detected = 0
25
       for (x, y, w, h) in faces:
           # ROI for mouth
26
27
           x1 = x
28
           h2 = int(h/2)
29
           y1 = y + h2
30
           mouthROI = gray_frame[y1:y1+h2, x1:x1+w]
31
32
           if detectShush(frame, (x1, y1), mouthROI, mouthsCascade):
33
                detected += 1
34
                cv2.rectangle(frame, (x, y), (x+w, y+h), (255, 0, 0), 2)
35
                cv2.rectangle(frame, (x, y), (x+w, y+h), (0, 255, 0), 2)
36
37
       return detected
38
39
40
   def run_on_folder(cascade1, cascade2, folder):
41
       if (folder[-1] != "/"):
42
           folder = folder + "/"
43
       files = [join(folder,f) for f in listdir(folder) if isfile(join(folder,f))]
44
       windowName = None
45
       totalCnt = 0
       for f in files:
46
47
           img = cv2.imread(f)
48
           if type(img) is np.ndarray:
                1Cnt = detect(img, cascade1, cascade2)
49
                totalCnt += 1Cnt
50
51
               if windowName != None:
52
                    cv2.destroyWindow(windowName)
```

```
53
                windowName = f
54
                cv2.namedWindow(windowName, cv2.WINDOW_AUTOSIZE)
55
                cv2.imshow(windowName, img)
56
                cv2.waitKey(0)
57
        return totalCnt
58
59
   def runonVideo(face_cascade, eyes_cascade):
60
        videocapture = cv2.VideoCapture(0)
61
        if not videocapture.isOpened():
62
            print("Can't open default video camera!")
63
64
        windowName = "Live_Video"
65
        showframe = True
66
67
        while(showframe):
68
            ret, frame = videocapture.read()
69
70
            if not ret:
71
                print("Can't_capture_frame")
72
73
            detect(frame, face_cascade, eyes_cascade)
74
            cv2.imshow(windowName, frame)
            if cv2.waitKey(30) >= 0:
75
76
                showframe = False
77
78
        videocapture.release()
79
        cv2.destroyAllWindows()
80
81
   if __name__ == "__main__":
82
83
        # check command line arguments: nothing or a folderpath
84
       if len(sys.argv) != 1 and len(sys.argv) != 2:
85
            print(sys.argv[0] + ":ugotu" + len(sys.argv) - 1 +
            "arguments.\squareExpecting\square0\square0r\square1:[image-folder]")
86
87
            exit()
88
        # load pretrained cascades
89
90
        face_cascade = cv2.CascadeClassifier(cv2.data.haarcascades + 'haarcasca<mark>de_frontalf</mark>
        mouth_cascade = cv2.CascadeClassifier('Mouth.xml')
91
92
93
        if(len(sys.argv) == 2): # one argument
94
            folderName = sys.argv[1]
95
            detections = run_on_folder(face_cascade, mouth_cascade, folderName)
96
            print("Totaluofu", detections, "detections")
97
        else: # no arguments
            runonVideo(face_cascade, mouth_cascade)
98
```